

TRD(TRD) FRAME PARTS LIST

Parts No.	Description	15	18	21	24	27	30	33
-----------	-------------	----	----	----	----	----	----	----

5/8in RAIL FRAME CARTON #2

1615	5/8in Rail L=1431mm(56-3/8")	20						
1618	5/8in Rail L=1431mm(56-3/8")		24					
1621	5/8in Rail L=1431mm(56-3/8")			28				
1624	5/8in Rail L=1431mm(56-3/8")				32			
1627	5/8in Rail L=1431mm(56-3/8")					36		
1630	5/8in Rail L=1431mm(56-3/8")						40	
1633	5/8in Rail L=1431mm(56-3/8")							44

TRD FRAME CARTON #2

1120	TradeWind Radius Top Seat L=1444mm(56-7/8")	10	12	14	16	18	20	22
------	---	----	----	----	----	----	----	----

TRD FRAME CARTON #3

2180	TradeWind Resin Upper Joint	10	12	14	16	18	20	22
2280	TradeWind Resin Lower Joint	10	12	14	16	18	20	22
2497	TradeWind Inside Seat Cover	10	12	14	16	18	20	22
2498	TradeWind Outside Seat Cover	10	12	14	16	18	20	22
Seat Cover Assembly Bolt Package								
0341	#12 Sheet Metal Screw	90	108	126	144	162	180	198

TRD FRAME CARTON #4

2398	TradeWind Vertical (52" High)	10	12	14	16	18	20	22
2399	TradeWind Vertical (54" High)	10	12	14	16	18	20	22
0022	Warranty	1	1	1	1	1	1	1
0023	Safety Decals	1	1	1	1	1	1	1
0024	Parts List + Frame Instruction	1	1	1	1	1	1	1
0025	Safety Booklet	1	1	1	1	1	1	1
0001	Round Instruction	1	1	1	1	1	1	1

SIDE WALL CARTON #1

8100	Plastic Edging	11	14	16	18	20	22	24
------	----------------	----	----	----	----	----	----	----

52" Wall Joint Bolt Package Packed in a Wall Carton.

0513	1/4" x 1/2" Truss Head Screw	26
0411	1/4 Reinforcing Washer	51
0611	1/4in Nut	26

54" Wall Joint Bolt Package Packed in a Wall Carton.

0513	1/4" x 1/2" Truss Head Screw	27
0411	1/4 Reinforcing Washer	53
0611	1/4in Nut	27

Printed in JAPAN
Nov 10, 2009